AMP CORE STUDIO

Owner's Manual

Copyright
Copyright 2024 Cherub Technology Co., Ltd. All rights reserved. NUX and **AMP CORE STUDIO** are trademarks of Cherub Technology Co., Ltd. Other product names mentioned in this product are the trademarks of their respective companies that do not endorse and are not associated or affiliated with Cherub Technology Co., Ltd.

Disclaimer
Whilst every effort has been made to ensure the accuracy and content of this manual, Cherub Technology Co., Ltd. makes no representations or warranties regarding the contents.

WARNING: IMPORTANT SAFETY INSTRUCTIONS
BEFORE CONNECTING, READ INSTRUCTIONS

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION: To reduce the risk of fire or electric shock, do not remove screws. No user-serviceable parts inside. Refer servicing to qualified service personnel.

CAUTION: This equipment has been tested and found to comply with the limits for a Class B digital device pursuant to Part 15 of FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The lightning symbol within a triangle means "electrical caution". It indicates the presence of information about operating voltage and potential risks of electrical shock.

The exclamation point within a triangle means "caution". Please read the information next to it before doing so.

1. Use only the supplied power supply or power cord. If you are not sure of the type of power available, consult your dealer or local power company.
2. Do not place near heat sources, such as radiators, heat registers, or appliances which produce heat.
3. Guard against objects or liquids entering the enclosure.
4. Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points or other risks. Refer all servicing to qualified service personnel.
5. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as when: the power supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, or has been dropped.
6. The power supply cord should be unplugged when the unit is to be unused for long periods of time.
7. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles and at the point where they exit from the apparatus.
8. Prolonged blistering at high volume levels may cause irreparable hearing loss and/or damage. Always be sure to protect your hearing.

Follow all instructions and heed all warnings
KEEP THESE INSTRUCTIONS!

WARNING
To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

FCC WARNING
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. **Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. This device has been tested for near-field general RF exposure statement. Device can be used in portable exposure condition without restriction.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Overview

Thank you for choosing the NUX AMP CORE STUDIO.

The AMP CORE STUDIO is a stereophonic platform amp modeler with cabinet simulation (IR) and other effects. It features 26 world-class guitar amplifier models, including F-type amp like Tweed, Twin, and Bassman; M-stripe amps like Plexi and JCM; modern high-gain amps like HBE, IIHL and Rectifier; as well as boutique amps such as the DC30, Mac 30, and AC30. The iconic TEAC-HX dBrid Box algorithms amp modelling offers a realistic amp feel and a highly responsive playing experience. With premium amp emulation and third-party IR loader support in a compact pedal, you can easily bring your favorite amp tones with you wherever you go.

The footswitch not only controls the AMP CORE STUDIO's bypass function but also allows you to toggle between SCENE1, SCENE2, and SCENE3 in sequence, enabling you to switch between different amp tones on the fly for example. You can set a clean tone for SCENE1, an overdrive tone for SCENE2, and a high-gain solo tone for SCENE3.

Featuring a TFT color LCD screen and three parameter knobs, you can easily adjust all parameters to create your own custom sound, with a clear and intuitive visual interface.

In addition to amp and IR effects, the AMP CORE STUDIO includes a noise gate (NG), equalizer (EQ), pitch fuzz (PF1), and a send & return (S/R) function. The built-in headphone jack allows for convenient practice without additional devices. Like a traditional amp, you can also connect an expression pedal to control a pedal-sized function, making it easy to integrate into your pedalboard and take anywhere.

The AMP/CORE/STUDIO edit software lets you customize all signal blocks and parameters. It includes 32 built-in IR cabinets and 12 empty slots for third-party IRs. The software supports conveniently WAV-format IR files, making it easy to load and import.

Additionally, the AMP CORE STUDIO supports USB audio streaming, functioning as an audio interface. It also provides MIDI, NUMPAD, and DRY OUT modes, depending on your needs.

** All of the brand and model names mentioned on this page are Trademarks of their respective owners, which are in no way associated or affiliated with NUX (Cherub) and Cherub Technology CO. LTD.*

Features

- 26 legendary amp models packed into a compact, pedal-sized form factor
- TEAC-HX dBrid Box amp modeling algorithm delivers authentic amp feel with ultra-responsive playability
- Premium IR loader supports 32 built-in cabinets and 12 empty slots for custom IRs
- 3 Scenes Modes allow seamless switching between different amp tones in real-time
- Built-in Noise Gate (NG), EQ, Patch Level (P.L.) adjustment, and Send/Return (S/R) function for versatile sound shaping
- Send/Return loop to easily integrate your favorite effect pedals
- Ultra-low latency of 1.2ms
- Wide dynamic range of 106dB for supreme sound quality
- 48kHz / 32-bit high-precision processor for crystal-clear audio performance
- Comes with AMP/CORE/STUDIO software for advanced sound editing and customization

Control Panel & I/O Jacks



- **POWER JACK**
- **MIDI USB/DATA ROUTING**
- **OUTPUT JACK**
- **HEADPHONE JACK**
- **Footswitch**
- **LCD DISPLAY**
- **MIDI USB/GLOBAL SETTING**
- **SEND JACK**
- **USB PORT**
- **KNOB 1/SCENE**
- **INPUT JACK**
- **RETURN JACK**
- **MIDI IN JACK**

POWER JACK: It is connected to the power adaptor. Negative Tip power with 9V DC, 2A power consumption is the power supply.

LCD DISPLAY: 1.9 inch TFT color LCD display.

KNOB 1/SCENE: Parameter Knob 1 is used to adjust the parameters corresponding to the screen and can be rotated or pressed.

KNOB 2/SLOOK ROUTING: Parameter Knob 2 is used to adjust the parameters corresponding to the screen and can be rotated or pressed. Press it will enter the SLOOK ROUTING page.

KNOB 3/GLOBAL SETTING: Parameter Knob 3 is used to adjust the parameters corresponding to the screen and can be rotated or pressed. Press it will enter the GLOBAL SETTING page.

INPUT JACK: 1/4" TS mono jack for connecting guitar, bass or other pedals.

OUTPUT JACK: 1/4" TS mono jack for connecting to audio interfaces, audio mixers, or amplifiers' effects return jacks.

SEND JACK: 1/4" TS mono jack for connecting the input of time-based effect (like) delay or reverb).

RETURN JACK: 1/4" TS mono jack for connecting the output of time-based effect (like) delay or reverb).

HEADPHONE JACK: 1/8" stereo jack for connecting headphones or active monitor speakers.

USB PORT: USB Type-C port for connecting to a computer via a USB-C to USB-A cable. Once connected, the AMP CORE STUDIO can be edited using the AMP/CORE/STUDIO software and used as an audio interface.

MIDI IN JACK: 1/8" MIDI input for connecting to the external MIDI devices, can be controlled by MIDI control change messages.

Footswitch: For controlling the AMP CORE STUDIO's SCENES or bypass status..

How to use

• PRESETS & SCENES

Power on the AMP CORE STUDIO and rotate the KNOB 1 to cycle through and adjust the 20 built-in presets.

Each preset includes 3 SCENE modes—S1, S2, and S3. Press the footswitch to cycle through and select the different SCENES in sequence.

• Adjust the tone

On the PRESET&SCENE page, pressing the KNOB 1 will navigate to the Amp block page.

Rotate the 1, 2, and 3 KNOBs to adjust the corresponding parameters displayed on the screen. Press the KNOB 3 to change the page, if multiple pages are available for the effect block.

Press the KNOB 2 to cycle through the effect blocks in the following order: Amp, IR, EQ, PL, S/R, NG.

Pressing the KNOB 1 will bypass the current effect block. Pressing KNOB 1 again will re-enable it.

Hold the KNOB 1 for 1 second to activate the GREEN ARROW. Once it's on, you can rotate the PARAMETER 1 knob to change the effect model. Hold the KNOB 1 again to exit model selection mode.

Press the footswitch to return to the PRESET&SCENE page.

• Global setting

Press the KNOB 3 to enter the GLOBAL SETTING menu, which contains six submenus: FS (Footswitch), PHONES, USB, PARA, DISPLAY, and Factory. Rotate KNOB 3 to select the desired submenu, then press to enter.

• FS

Rotate the KNOB 3 to select between BUFFER BYPASS mode or TRUE BYPASS mode. Rotate the KNOB 2 to toggle SCENE 3 ID3 on or off. If SCENE 3 is off, only two SCENES will be available for selection, allowing you to cycle through them using the footswitch.

Press KNOB 3 to return to the upper menu.

• PARA. FOLLOW

If you enable PARA. FOLLOW, the AMP CORE STUDIO will remember the parameters when you leave and return to the current effect model. If PARA. FOLLOW is disabled, the effect model will revert to its default parameters when selected again.

Rotate KNOB 3 to enable or disable the PARA FOLLOW.

Press KNOB 3 to return to the upper menu.

• DISPLAY

Rotate KNOB 3 to adjust the display brightness.

Press KNOB 3 to return to the upper menu.

• Bypass

Hold the footswitch for 1 second to bypass all effect blocks. The preset number on the screen will change from blue to gray. Holding the footswitch again will re-enable all the effect blocks.

• Saving the presets

After changing a preset, an STAR will appear on the PRESET & SCENE page, indicating that the preset has been modified but not yet saved. Press and hold the KNOB 1 to enter the name editing page.

Rotate KNOB 1 to select the preset number where you want to save the changes. Rotate KNOB 2 to adjust the letter selection sequence. Rotate KNOB 3 to choose the corresponding character for the name.

Press KNOB 3 to save the changes.

Press KNOB 1 to adjust the sequence of SCENES in the current preset. Rotate KNOB 1 to select the SCENE you want to adjust, rotate KNOB 2 to choose the new position for the selected SCENE.

Press KNOB 3 to save the changes to the current preset.

• Block Routing

On the PRESET & SCENE page, press the KNOB 2 will navigate to the signal chain page.

Rotate the KNOB 2 to select the effect block. Press either the KNOB 2 or KNOB 3 to quickly toggle the selected block on or off.

Press and hold the KNOB 2 until the block arrow turns red. Rotate the knob to adjust the block sequence according to your preference, and press the KNOB 2 again to confirm.

Press the footswitch to return to the PRESET & SCENE page.

• Quick Level Adjust

On the PRESET & SCENE page, rotate KNOB 2 or KNOB 3 to enter the Quick Level Adjust page. Rotate KNOB 2 to adjust the headphone output level, and rotate KNOB 3 to adjust the Patch Level.

• PHONES

Rotate the KNOB 3 knob to adjust the global headphone output volume.

Press KNOB 3 to return to the upper menu.

• USB SETTING

In the USB page can adjust the USB audio setting when using the AMP CORE STUDIO as a USB audio device.

Rotate KNOB 1 to adjust the INPUT LEVEL for USB input.

Rotate KNOB 2 knob to adjust the OUTPUT LEVEL for USB output.

Rotate KNOB 3 knob to adjust the USB audio mode included REAMP, NORMAL and DRY OUT.

Press KNOB 3 to return to the upper menu.

• FACTORY

Rotate the KNOB 3 to choose between FACTORY RESET or HARDWARE INSPECTION. Press the KNOB 1 to enter. Press KNOB 3 to return to the upper menu.

NOTE: Before performing a factory reset, please back up your presets using the AMP/CORE/STUDIO software.

Connections

• In Stage

Connect a pedalboard containing the AMP CORE STUDIO to a mixer or PA system for excellent tone, control, and flexibility in live situations. Monitor through the house system or in-ear monitors. *For a dedicated personal on-stage monitor, connect your pedalboard to a powered FRFR speaker.*

NOTE: The AMP CORE STUDIO is designed to deliver amp and cab tones, so it is not ideal to use it in front of a guitar amp.

If you are connecting a guitar amplifier while using the AMP CORE STUDIO, please turn off the IR when using it with the guitar amplifier, and connect the OUT to the RETURN of the guitar amplifier.

If you need to connect sounds from both the guitar amplifier and DI signal simultaneously, you can set the IR at the end of the signal chain by placing the S/R module before the IR. In this configuration, the SEND from the AMP CORE STUDIO will provide only the amp sim signal. The OUT can then be connected to the SR for a complete amp and cab sim signal, while the SEND connects to the RETURN of the guitar amplifier, outputting only the preamp signal from the amp section.

• In Studio

Connect AMP CORE STUDIO directly to a recording interface for great guitar tone instantly without the need to set up an amp or mic/speakers.

• At Home (Silent Practice)

Connect headphones or monitors directly to AMP CORE STUDIO's 1/8" PHONES output to experience immersive classic amp tones in a natural sounding room without an amp.

Edit Software

You can find the AMP CORE STUDIO edit software tutorial on the NUX59 YouTube channel.

The software allows you to load preset parts/fx units and customize your favorite amp models to create your own sound. You can adjust the signal block order and routing, deeply tweak all block parameters, and even export or import presets.

MIDI Control

You can control the AMP CORE STUDIO with an external MIDI device. In the AMP/CORE/STUDIO software, there is a list of functions that are controlled when a control change message (channel 1–16, with controller number/value) is received from an external MIDI device.

When switching patches using Program Change messages transmitted by an external MIDI device, you can setup Program Changes as below.

Program Changes for switching patches:

MIDI Type: Program Change

MIDI Channel: 1

PC number: 0–19

Please visit www.nuxaudio.com to download AMP/CORE/STUDIO, which includes the MIDI CC/PC parameter control table.

Specifications

• Sampling Frequency:	48kHz
• AD CONVERTER:	24bit
• Signal Processing:	32bit
• Frequency response:	20Hz-20kHz
• Noise Level:	<-100dBu
• Dynamic Range:	105dB
• Power Consumption:	11mA-120mA
• Input:	9V, 1A
• Output:	1/4" SEND, PHONES
• Display:	TFT color LCD display
• Power:	9V, supplied by the power adaptor

NUX

AMP CORE STUDIO

使用说明书

请注意！重要安全说明。
在连接使用前，阅读以下说明。

警告：为减少火灾或触电的危险，请将机器置于防雨和潮湿环境中。

注意：为避免人员受伤和财产损失，请仅使用和安装本产品，遵循本产品内详细的操作指导书。

注意：本产品已经过调试，证明符合CE指南中适合的商标规则。操作过程也应当遵守以下两个条件：(1) 本产品不会产生有害干扰；(2) 本产品必须接受任何干扰，包括可能会导致非正常操作的干扰。

1. 请以全部Mini KZS-35W电源适配器（规范）。 如果电路发生过热情况，请停止使用并与设计的授权维修商联系。 如果您不确定可能的危险类型，请咨询您的经销商。
2. 请在恶劣的天气条件下，如雷雨，电暴，或者已产生雾气的条件下，请勿使用。
3. 请勿让液体、灰尘及其它物质进入设备内部。
4. 请勿试图自行维修本产品。如需维修，请联系您附近的授权经过培训的维修人员。
5. 当本产品遭遇电路短或插头损坏、不规则操作，进水等情况时，请断开电源并立即联系售后服务。
6. 请勿长时间不使用本产品，应拔掉电源线。
7. 请勿将本品放在热源，通风口或密闭表面附近。
8. 人员培训明确指南需遵守所列指令明确无法规定的情况，请参阅到明 "安全预防"。

请遵守所有的指示和注意所有警告并保留这份说明！

产品简介

感谢您选择NUX AMP CORE STUDIO音箱模拟效果器。

AMP CORE STUDIO是一款具有强头模型，精准模拟（功能详细设计）和其他效果器自的音箱模拟器，现在有4个闪存槽用于3个 AMP CORE STUDIO效果了对应世界著名的音箱音箱模型，包括著Sweet、Twin和Supreme等经典的高级音箱模型，Pro和Custom等体现高级音色的音箱头模型，HIR、VH4和Archon等现代高增益音色的顶头模型，同时包含包括EQ、DC30、Mesa等著名音色的音箱模型。通过NUX的云音箱APP，用户还可以在线浏览和管理这些音箱模型，AMP CORE STUDIO除了配置这些音箱模型外，它们以连接成的录像设置多音箱和动态音箱等多音箱了为用户在录音真实音箱时的影响体验，同时AMP CORE STUDIO还支持第三方IR的导入和在应用，使您能够从您的录音音箱的音箱音色进行更加准确。

AMP CORE STUDIO的环切下可以使用Boss的效果直通开，还可以作为USB音箱模式仅供录制，ES5CTRL、SCENE2和SCENE3的循环切换，使您可以在一个预设中快速切换不同音箱的音色。例如，您可以在SCENE1设置一个音箱清音音色，SCENE2设置一个音箱过载音色，SCENE3设置一个音箱高增益音色，简单地使用音箱高速踏板一样，通过简单地实现不同预设的音色。

通过内置的可以为音频，三个带双后脚码的录音模拟智能切换以设置录制的指向，您可以在唯一，清晰每了地各自信息自己指向时的音色，适配不同应用场景使用。

产品特点

- 六面闪烁世界著名的经典音箱音箱模型
- 可为AC-和过度音箱音箱模拟器，高度还原了音箱本身的音色，同时提供快速敏感的录音效果手感和动态音箱听觉，还原了录音真实音箱时的触感体验
- 三个面闪烁特殊模型，12个空白过度效果三方闪烁A
- 三种MIDI通道模式，可实时无缝地切换不同音箱模拟音色
- 内置96种预设，预设数量很多，方便设置音箱闪烁以及不仅满足音箱设置要求，方便灵活地调整音色要求
- 内置Bluetooth接口，可接入音箱的周边效果包括踏板一起使用
- 双个3段可切换音箱设计
- 15bit的高动态范围保证了音色的动态和不损失细节
- 44kHz/32bit高精度处理，确保了音箱采样音色的准确
- 可通过电脑端AMP CORE STUDIO进行快速、深度的音色编辑和功能自定义
- 3个闪爆机的录音环境，更高的音色多样性


面板介绍与连接图示



❶ 电源接口
❷ 3.5mm耳机插孔
❸ 踏板连接器
❹ 3.5mm 辅助输入
❺ USB 接口
❻ 电源开关
❼ 3.5mm 输出
❽ 输出/监听/编辑
❾ 输入/录音
❿ Return 接口
⓫ MIDI 输入接口

如何使用AMP CORE STUDIO

●闪烁时切换预设和SCENE场景




旋转旋钮↑

和AMP CORE STUDIO键上电源，旋转旋钮↑可以在内置的3组PRESET场景中循环切换。



每一组预设包括两个SCENE场景模式选择 - S1、S2和S3。按下旋钮↑可以在S1、S2和S3场景中循环切换。

●Bypass直通



效果启用　　效果直通

按下旋钮↑并保持按住0.5秒后，AMP CORE STUDIO会切换为Bypass效果直通模式，通过再次按下旋钮↑并保持0.5秒后，再次恢复为按下旋钮↑并保持0.5秒后恢复到打开效果。

●预设保存



修改预设参数后，在预设和场景参数开启下，用户在完成所有设置参数后，"*"，表示当前预设参数发生改变未进行保存时，此时按下旋钮↑可以保存当前预设参数，通过再次按下旋钮↑可以将当前预设参数保存到当前预设中。

按下旋钮↑可调整场景在当前预设下的SCENE场景顺序。

旋转旋钮↑选择需要进行调整的SCENE场景的位置，旋转旋钮↑可选择需要的当前SCENE场景的预设SCENE场景的位置（重复），按下旋钮↑可把修改场景的到当前预设中。

●效果器



在预设和场景开启下，按下旋钮↑可进入效果调整界面。


旋转旋钮↑选择需要调整的效果模块，在当前界面下通过按下旋钮↑或旋钮↑选择开关选中的效果模块。



按下开保持旋钮↑至效果模块上的箭头变成红色，此时可旋转旋钮↑调整当前效果模块的参数，通过再次按下旋钮↑确认。

按下旋钮↑可将全部预设和场景参数开启。

●音量快速调节



在预设和场景开启下，旋转旋钮↑或旋钮↑进入音量快速调节界面，此时旋转旋钮↑可调整所对应当前，旋转旋钮↑可调整当前预设的输出音量。

●USB SETTING USB音箱设置



通过访问NUX AMP CORE STUDIO电脑连接，可将AMP CORE STUDIO充当USB声卡使用，在USB音箱设置界面下，可对AMP CORE STUDIO的USB音箱模式和输入输出等可进行调整。

旋转旋钮↑可调整USB音箱模式输入电平大小。

旋转旋钮↑可调整USB音箱的输出电平大小。

旋转旋钮↑可调整USB音箱模式，内含DAW模式、NORMAL模式和DRY OUT三种模式。

按下旋钮↑可返回至上一级菜单。

●PARA. FOLLOW参数记忆设置



如果启用NUX FOLLOW参数记忆设置，AMP CORE STUDIO将在切换预设的过程当前设置参数，如果禁用NUX FOLLOW参数记忆设置，重新选择预设时将会恢复到预设参数。

旋转旋钮↑可以启用或关闭NUX FOLLOW参数记忆功能。

按下旋钮↑可返回至上一级菜单。

●FACTORY出厂设置



旋转旋钮↑可选择FACTORY RESET恢复出厂设置或HARDWARE INSPECTION硬件检测。

按下旋钮↑可进入相应的设置界面。

按下旋钮↑可返回至上一级菜单。

注意：在恢复出厂设置后，将会将使用AMP CORE STUDIO软件备份设置，以免数据丢失。

连接场景

●舞台场景

将包含AMP CORE STUDIO的效果器电连接到调音台，如图A系统，以及现场演出中获得出色的音色。控制和演员，可以通过使用调音师系统或现场进行监听，把效果与你个人舞台监听，可以将踏板连接到舞台中的地板。


01
01
01