NUX Mighty Plug Pro Firmware Update Guide



Receipe

- [x] Computer running Windows 10 or later or macOS 10.10 or later.
- [x] the NUX Mighty Plug Pro
- [x] USB-C data/sync cable(Included)
- [x] Quality USB-C to USB Adapter(If your computer only comes with USB-C ports)
- [x] A little patience [1]

Step by Step Guide

1. Download the firmware update kit & Install the **NUX Device Updater**

   1.1 Download the firmware update kit from the Mighty Plug Pro product webpage.


   1.2 Unzip the downloaded file to a directory of your choice.

   1.3 Install the NUX Device Updater. [2]

2. Put the Mighty Plug Pro into DFU mode and connect it to your computer.

   2.1 Connect your Mighty Plug Pro to your Mac or PC using the incuded USB-C cable.

   2.2 Run the in **NUX Device Updater** from the applications folder(Mac user) or the start menu(Windows), you'll see the following interface:




2.3 Enter DFU mode:

- a. Press and hold the [PRESET SWITCH] button.
- b. Power on the Mighty Plug Pro by pressing the [POWER/MUTE] Button on the side of the unit.




- c. Release both buttons until you see the prompt message "(No device found)" turned into "Device Connected", at this point the [PRESET SWITCH] indicator should blink in **BLUE** (This should only take 3-5 seconds.):




3. Select the new firmware file & start upgrading the firmware.

3.1 Select the new firmware file (the binary file with '.bin' extension).




WARNING:


- Please make sure that the selected firmware is actual for the NUX Mighty Plug Pro. Otherwise, you may brick your Mighty Plug Pro or cause it to malfuction.
- Do NOT unplug anything during the upgrading process.



3.2 Click "Start Update" to start upgrading the firmware. It takes roughly 3-5 minutes to finish, during this process, **the [PRESET] switch** blinks in **ORANGE**.



3.3 Once the firmware is successfully upgraded, the following alert window should pop out notifying you that the upgrade is completed, and the [PRESET SWITCH] indicator start to blink in **GREEN**.



4. Finish Updating.

    4.1 Close the "NUX Device Updater"

    4.2 Disconnect the USB-C cable from the Mighty Plug Pro.

    4.3 Grab your guitar/bass and try out the new features and tones.

---

1. If you have any further problems, please email us @ info@cherubtechnology.com or usa@cherubtechnology.com ↩

2. The latest version of NUX Device Updater (V2.1.12.10) by far requires installation. ↩